

Installation Instructions

WBIS Wall Shower Installation

1. Layout and cut the openings for the shower head panel, the push button panel and if applicable the soap dish. The shower head is at 72" above the finished floor and the push button is 54" above the finished floor. Reference print for cutout sizes.
2. Before mounting the shower verify that the all thread rods are long enough to reach through the cutouts in the wall.
3. Mount the shower to the wall with the nuts and the backer bars provided. Make sure all the nuts are tighten down all the way.
4. Mount the valve to the chase side of the wall and connecting the shower head and push button to the valve.

